


cave module






CV 60 + CV STR

installation manual




bejot:


CONNECTORS




PEOPLE



ADDITIONAL TOOLS




ATTACHED




M6x25


x32




CV 60




CV STR






1





2






3





4






5





6




7




8






9





10





11




12




13




14






15




16



17



x2



Bejot Sp. z o. o.

ul. Wybickiego 2A, Manieczki, 63-112 Brodnica n. Poznania, POLAND

tel.: +48 (61) 281 22 25, e-mail: biuro@bejot.eu

www.bejot.eu

edition 10/2021