


gummy bear


GB 4P, GB TM, GB TW A, GB TWB, GB ROTO

installation manual




bejot:


parts






additional tools



attached




1





2



GB ROTO



3





4




5

7






6


GB 4P






7




8





8



9




7




10


GB TM





11



12




13





14

GB TW A


4





15



16




17






18

GB TW B


5





19



20



21



Bejot Sp. z o. o.

ul. Wybickiego 2A, Manieczki, 63-112 Brodnica n. Poznania, POLAND

tel.: +48 (61) 281 22 25, e-mail: biuro@bejot.eu

www.bejot.eu

edition 01/2022