



PERFORMANCE • DESIGNED FOR HUMAN

## RH ACTIV

An RH chair is the perfect work tool, a chair that puts you in an optimal position all day, every day. A few simple adjustments is all it takes to make your RH chair fit your individual anatomy. RH chairs support an upright posture and active sitting, increasing your performance.

If you are looking for a chair that can be adapted to suit different people in different office environments, RH Activ is a natural choice. RH Activ is easy to use and will give you good support even if you sit for long hours. RH Activ is also available in ESD and cleanroom editions.

### Ergonomics

Providing complete support in any working position, enabling you to always sit correctly and breathe properly.

- Seamless and separate adjustable seat and back angle.
- Pictograms on all handles and levers make the chair easy to use, easy to understand.
- Replaceable seat and back, easy to change.
- A user-friendly multiuser chair, were you sit well for both short and long periods.
- Can be tailor-made to almost all tasks and environments. Two seats, two backs, five gas stems, extra reinforced seat and back upholstery for heavy use, cashier-seat, and foot-ring.

### Quality

- 10 year guarantee

Flokk is certified in accordance to:

- ISO 9001
- ISO 14001

RH Activ is certified in accordance to:

- EN 1335-1-2-3
- Möbelfakta
- BS 5459
- IEC 61340 (ESD)
- ISO 1400 644-1 (Cleanroom)

### Environment

- Supports companies' environmental profile and credibility (CSR) - Cradle to cradle proof
- Easy to disassemble and no harmful chemicals
- ISO 14025 (EPD)
- GREENGUARD GOLD

### Design

Materials and surfaces communicating comfort and wellbeing through bodyfitting forms. Expressing human performance.

### Fire classifications

Foams and standard fabrics are tested to BS/EN 1021-1&2 (cigarette & match). Foam and fabric according to BS-5852 ignition source 5 (crib 5) can be delivered on request. Please contact our customer service for further information.

### Maintenance

Vacuum clean the chair with a furniture brush or wipe it with a clean cloth or sponge slightly dampened with lukewarm clean water. Do not remove any plastic parts or attempt to open the seating mechanism. Contact your Flokk dealer if the chair requires servicing or maintenance.

See [flokk.com/rh](http://flokk.com/rh) for RH Activ interactive user instruction guide.





RH ACTIV 200



RH ACTIV 202



RH ACTIV 220



RH ACTIV 222

CHAIR MODELS AVAILABLE:

RH ACTIV

- 200 – Medium back, medium seat
- 202 – Medium back, large seat
- 220 – Large back, medium seat
- 222 – Large back, large seat
- ESD
- ESD CLEANROOM
- CLEANROOM

MEASUREMENTS	ACTIV 200	ACTIV 202	ACTIV 220	ACTIV 222
Seat depth with seat slide	390-445 mm	420-475 mm	390-445 mm	420-475 mm
Seat depth	430 mm	460 mm	430 mm	460 mm
Seat width	440 mm	460 mm	440 mm	460 mm
Seat Height - standard gas stem	392-522 mm	392-522 mm	392-522 mm	392-522 mm
Seat angle adjustment	+6°-7°	+6°-7°	+6°-7°	+6°-7°
Height of lumbar support above the seat	170-253 mm	170-253 mm	170-253 mm	170-253 mm
Backrest height	295 mm	295 mm	430 mm	430 mm
Backrest width	370 mm	370 mm	370 mm	370 mm
Back angle adjustment	23°	23°	23°	23°
Height of armrest above seat	190-290 mm	190-290 mm	190-290 mm	190-290 mm
Distance between armrests	375-576 mm	375-576 mm	375-576 mm	375-576 mm
Diameter of base	590 mm	590 mm	590 mm	590 mm

OPTIONS

- 1 Exchangeable pad
- 2 Reinforced front edge on backrest and seat
- 3 Armrest 8E, grey or black (height, depth, width)
- 4 Armrest 8S, grey or black (height, width, rotating)
- 5 Base 5N chrome-plated steel
- 6 Base 5F polished aluminium
- 7 Base 5F, black lacquered aluminium
- 8 Base 5F, grey lacquered aluminium
- 9 Footring 6F
- 10 Glide 7K
- 11 Castors 7G lock automatically under load
- 12 Castors for hard floors
- 13 Castors for soft floors

GAS STEMS

- B, approx. 397-527 mm
- E, approx. 600-872 mm
- D, approx. 510-685 mm
- A, approx. 437-573 mm
- 4 FL, approx. 370-460 mm
- \* see our price list for different combinations.

For other options see the RH Price List.

The design and specifications of RH Chairs' products are developed on an ongoing basis and the above formulations should not be perceived as completely final.

ESD

RH Activ is available as ESD Chair. Flokk provides a 5 year warranty for ESD, conditional on casters and treads being cleaned regularly with a suitable cleaning agent. The chairs are approved in line with IEC 61340(ESD). To work effectively the chair should be used in an ESD-adapted environment.

RH Activ Cleanroom

Work chair for cleanroom environment, designed to release a minimum of particles and easy to clean. Approved according to ISO Class 4 and ISO Class 5.

RH Activ Cleanroom ESD

Work chair for cleanroom environment designed to deflect static electricity, release a minimum of particles and easy to clean. Approved according to ISO Class 4.