HOW TO ADJUST YOUR
RH SECUR24

DESIGNED FOR HUMAN PERFORMANCE

1
HEIGHT OF THE CHAIR

2
SEAT DEPTH
*OPTIONAL FOR 3130

3
BACKREST ANGLE/
TILT REARWADS

4
LOCK/UNLOCK THE
DYNAMIC TILT

5
SET THE ANGLE OF THE
BACKREST

6
TILT RESISTANCE/
COUTER PRESSURE

7
ADJUST THE LUMBAR
SUPPORT

8
ARMREST HEIGHT

9
ARMREST ANGLE

10
ADJUSTABLE NECKREST
IN DEPTH

11
FEEL FREE TO CHANGE
SETTINGS

11
Interactive user instruction

rh